



RM24200 QUICK INSTALLATION GUIDE


Major Components




Front Panel Controls and Indicators




Maintaining Front Door Filter




Rear Window Configuration




Top Cover Opening



Installing PS/2 Power Supply




Installing Internal 2.5" HDD



Installing 5.25"/3.5" Drive Bay (with 3.5" HDD or FDD)


Installing 5.25" ODD

1. Release two screws on top of the drive bay to take it out from the chassis
2. Release one screw at the right side of the drive bay
3. Take out the upper front cover
4. Slide the 5.25" ODD into the drive bay assembly
5. Use eight screws to fix on both left and right sides of the drive bay




Installing 3.5" HDD

- Slide 3.5" HDD into drive bay, and use four quakeproof screws to fix it at the bottom of the drive bay



Installing FDD

1. Remove the lower front cover of the drive bay
2. Slide FDD into drive bay
3. Use four screws to fix it on both left and right sides of the drive bay



Installing 5.25"/3.5" Drive Bay

1. Slide the 5.25"/3.5" drive bay into the chassis
2. Use two screws to fix it on the chassis

Installing 5.25" ODD/Slim ODD Drive Bay


Installing 5.25" ODD

1. Release two screws on top of the drive bay to take it out from the chassis
2. Release one screw at the right side of the drive bay
3. Take out the upper front cover
4. Slide the 5.25" ODD into the drive bay assembly
5. Use eight screws to fix on both left and right sides of the drive bay



Installing Slim ODD

1. Remove the slim ODD front cover
2. Slide the slim ODD into the bay and use four screws to fix it



Installing 5.25" ODD/ Slim ODD Drive Bay

1. Slide the 5.25" ODD/slim ODD drive bay into the chassis
2. Use two screws to fix it with the chassis


Installing Middle Fan

- Use a screw to fix the fan assembly (fan + finger guard+ fan bracket) on the rear side of internal 2.5" HDD on the chassis



Installing Rear Fan

- Use a screw to fix the fan assembly (fan + finger guard+ fan bracket) on the rear window



Installing Intrusion Switch

